

## Installation Instructions for AX-ADXSVI-GM1

### AX-ADXSVI-GM1

#### APPLICATIONS

<b>BUICK</b>	
Enclave	2008-up
Lucerne	2006-2011
<b>CADILLAC</b>	
Escalade	2007-2011
(only to be used when replacing an amplified system)	
DTS	2006-2011
(only to be used when replacing an amplified system)	
SRX	2007-2009
(only to be used when replacing an amplified system)	
<b>CHEVROLET</b>	
Avalanche	2007-up*
Captiva Sport	2012-up
Cheyenne	2012-up *
Equinox	2007-2009
Express	2008-up
Impala	2006-2013
Impala limited	2014
Monte Carlo	2006-2007
Silverado (new body)	2007-13*
Silverado 2500/3500	2014 *
Suburban	2007-2014*

Tahoe	2007-2014*
Traverse	2009-up

<b>GMC</b>	
Acadia	2007-up
Savana	2008-up
Sierra (new body)	2007-13*
Sierra 2500/3500	2014*
Yukon/XL	2007-2014*

<b>HUMMER</b>	
H2	2008-2009

<b>PONTIAC</b>	
Torrent	2007-2009

<b>SATURN</b>	
Outlook	2007-2010
Vue	2008-2010

<b>SUZUKI</b>	
XL-7	2007-2009

\*Non-navigation models only

#### KIT FEATURES

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (retained accessory power)
- Used in non-amplified systems or when replacing amplified system
- Provides NAV outputs (parking brake, reverse, and V.S.S.)
- Prewired ASWC-1 harness included (ASWC-1 sold separately)
- High level speaker input
- USB updatable

#### Note:

- 1) This harness must be used in conjunction with the AX-ADXSVI
- 2) All chimes will be lost when using this harness

#### WIRING THE AX-ADXSVI-GM1

- Connect the **Yellow** wire to the radio's 12 volt battery or memory wire.
- Connect the **Black** wire to the radio's ground wire.
- Connect the **Red** wire to the ignition wire of the aftermarket radio.
- Connect the **Orange** wire to the illumination wire of the aftermarket radio. If the aftermarket radio has no illumination wire, tape off the **Orange** wire.
- Connect the **Blue** wire to the antenna turn on wire of the aftermarket radio.
- Connect the **White** wire to the left front positive speaker output of the aftermarket radio.
- Connect the **White/Black** wire to the left front negative speaker output of the aftermarket radio.

(continued on next page)



- Connect the **Gray** wire to the right front positive speaker output of the aftermarket radio.
- Connect the **Gray/Black** wire to the right front negative speaker output of the aftermarket radio.
- Connect the **Green** wire to the radio's left rear positive speaker output.
- Connect the **Green/Black** wire to the radio's left rear negative speaker output.
- Connect the **Purple** wire to the radio's right rear positive speaker output.
- Connect the **Purple/Black** wire to the radio's right rear negative speaker output.

The following wires are for the aftermarket radios that have navigation built in.

- Connect the **Light Green** wire to the parking brake wire of the aftermarket navigation radio (if applicable).
- Connect the **Blue/Pink** wire to the VSS or speed sense wire of the aftermarket navigation radio (if applicable).
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio (if applicable).
- Cycle the key, by turning the ignition on for 30 seconds. Then off and on again to test the radio.

### ASWC-1 (if installing)

After the XSVI is initialized, plug in the ASWC-1 into the 12-pin harness of the AX-ADXSVI-GM1 and refer to the ASWC-1 instructions.

### IMPORTANT WARNING

This product includes instructions for installation which must be carefully followed. The instructions are worded in such a manner to assume that the installer is capable of completing these type of electronic installations. If you are unclear as to what you are instructed to do or believe that you do not understand the instructions so as to properly and safely complete the installation *you should consult a technician who does have this knowledge and understanding.*

**Failure to follow these instructions carefully and to install the interface as described could cause harm to the vehicle or to safety systems on the vehicle. Interference with certain safety systems could cause harm to persons as well. If you have any questions in this regard please call the Help line or Metra at 1-800-221-0932 for assistance.**



**KNOWLEDGE IS POWER**  
Enhance your installation and navigation skills by  
enrolling in the most recognized and respected  
installer training program in the industry.  
Log onto [www.installerinstitute.com](http://www.installerinstitute.com) or call  
800-354-6765 for more information and take steps  
toward a better tomorrow.



Metra recommends MECP  
certified technicians